

39-00208

YAMAHA VENTURE SLIP-ONS

Thank you for buying a BUB! We are committed to producing a quality product that with proper installation and care should last for many years to come. If you ever have any questions, feel free to give us a call.

INSTALLATION

Before removing your stock mufflers, remove the saddlebags. This is done by opening the bags and removing the two bolts that attach them from inside. Once this is done, loosen the muffler clamps and remove the rear mounting hardware. Remove mufflers.

The next step is to prepare your BUB Slip-Ons for installation. Slide the muffler clamps over the ends of the mufflers with the allen bolt on the bottom facing out. We recommend putting some hi-temp silicone seal on the mating surfaces of the muffler inlet and the last inch of the head pipe. Slide the mufflers in place with the clamp covers facing out.

With the stock rubber grommets and washers in place, insert the 3/8 x 1 3/4" bolts provided, and back up with flat and lock washers, followed by the hex nuts. Check proper alignment of the mufflers and tighten in place.

DETAILS, DETAILS

Clean the pipes thoroughly before firing the bike as grease or fingerprints will become permanent with heat! Check all fasteners after the first ride, and again at all service intervals.

Have fun and thanks for buying a BUB!

BUB ENT. 180 Spring Hill Drive, Grass Valley, CA 95945
ph (530) 477 7490 / (800) 934 9739 Fax (530) 477 7489
www.bub.com